

Keep Right USA

Thank You for your purchase!

Please call customer service at (951)905-8244 if there is a problem with your order or if you have any questions.

Transfer Decal Installation

Do Not apply decal in direct sunlight.

Apply decal in temperatures between 60 and 80 degrees Fahrenheit.

Inspect decal for damage or defects prior to installation.

Required Items: Installation squeegee, masking tape, glass cleaner, paper towels, razor blade, straight-razor (scraper), measuring tape or ruler.

1. Clean windshield thoroughly with 409 or like cleaner. Use a straight razor to remove any build-up.
2. Clean windshield with glass cleaner.
3. Position decal on windshield. Secure center with masking tape. Use more than one piece of tape if necessary. (See diagram below to adjust for curve of windshield)
4. Separate half of decal from backing. Cut backing along tape with razor blade.
5. Hold end of decal and squeegee from center outward. Remove tape, separate other half of decal from backing and squeegee from center outward.
6. Remove transfer tape from decal.
7. Apply wax or rain-x to decal and windshield. This will keep the wipers from damaging the decal during normal use.

To adjust decal to the contour of your windshield use the following cut points. After positioning decal and securing center with tape (R I G), cut decal between the “P” and “R”. Adjust “KEEP” to curve of windshield and secure with tape. Repeat with “HT” and “Arrow”. Proceed to step 4.



Additional information regarding transfer decal installation can be found online.

www.KeepRightUSA.com